

Keiner dieser Artikel hat eine Batterieleistung, somit wird **KEIN** UN.38.3 Report benötigt!

Art.-Nr.:	FSE	Eno-Art.-Nr.
1-57-1400-0	CC 9048	069278
1-57-1700-0	CC 9058	069264
1-57-1500-0.01	CC9068	106838
1-57-1501-0.01	CC9068	nicht angelegt
1-57-1780-0	CC 9056 Plus	114858
Art.-Nr.:	Crade S9	
0-02-37-1125-0	S9 Cradle - Works with iPhone X	110735
0-02-37-1121A-0	S9 Cradle - Works with iPhone 6 Plus / 6s Plus / 7 Plus	105158
0-02-37-1120A-0	S9 Cradle - Works with iPhone 6/6s/7	105157
0-02-37-3300-0	S9 Cradle universal XXL	084811
0-02-37-3400-0	S9 Cradle Universal 3XL	097967
0-02-37-xxxx-0	S9 für iPhone 11	diverse
Art.-Nr.:	Crade S8	
0-02-28-0300-0	S8 Cradle Universal XXL	084812
0-02-28-0340-0	S8 Cradle Universal 3XL	097966
0-02-22-0320A-0	S8 Cradle - Works with iPhone 6/6s/7	105361
0-02-22-0321A-0	S8 Cradle - Works with iPhone 6 Plus / 6s Plus / 7 Plus	105362
0-02-22-0326-0	S8 Cradle - Works with iPhone X	110732
Art.-Nr.:	CarPhone	
1-92-0001-0	BURY CP 1000 CarPhone	069770
Art.-Nr.:	CL 1010 Time	
1-75-0001-0	CL 1010 Time	053331
Art.-Nr.:	System 9	
0-07-22-0001-0	Wieszak System 9 M-545	025054
Art.-Nr.:	System 8	
1-44-0100-24	Uni CarTalk 4 PtP	nicht angelegt
1-44-0100-32	UNI CarTalk, version IV - no sleeve	050973
1-44-0100-06	UNI CarTalk, version IV - mit LS	051216
Art.-Nr.:	PowerMount	
01.1888.000A	POWERCHARGE Qi	102614
01.1888.000A.01	POWERKIT Qi	102609
01.1888.000A.05	POWERKIT Qi FORD	nicht angelegt
01.1888.000B	POWERCHARGE USB	102615
01.1888.000B.01	POWERKIT USB	102610
01.1888.000B.03	POWERKIT USB FORD	nicht angelegt
01.1888.000B.04	POWERKIT USB Fraport	nicht angelegt
01.1888.000C	POWERCRADLE PASSIVE	102616
01.1888.000C.01	POWERKIT PASSIVE	102611
01.1886.000	POWERBASE	102612
01.1887.000	POWERFLEX	102613
01.2143.000A	POWERWINDOW Qi	nicht angelegt
01.2143.000B	POWERWINDOW PASSIVE	nicht angelegt
01.1917.000	S8/S9 POWERMOUNT Adapter	106771
Art.-Nr.:	Zubehör	
0-12-02-0023-0	pilot CC9048,	111647
0-07-0404-0	USB C Adaptor	106773
0-07-0258-0.01_LF	Cable with micro USB	071414

0-07-0258-0.02_LF	Cable with mini USB	071415
0-07-0258-0.04_LF	Cable with Nokia N-series jack	071416
0-07-0258-0.04_LF	Charging Cable Pack	071416
0-07-0258-0.08_LF	Charging Cable Pack	083198
0-99-02-0001-0	DC/DC Converter	013678
0-ZVB6330	Fragrance Pad - Freedom	101304
0-ZVB6331	Fragrance Pad - Golden State	101305
0-ZVB6329	Fragrance pad - Fresh Boost	101303
0-23-00-0125-0	Little-Flat Antenna GSM Fakra	070635
0-23-00-0029-0	Antenna Little Flat 3 - (M - 319)	nicht angelegt
0-18-00-0029-0	audio switch box AC 5120	029818
04-27-0008-0	AC 5140 - connecting box	nicht angelegt
07-25-0015-0	Wieszak CL 1010 Time	058831
0-07-25-0006-0	Wieszak CC9058/CC9060/CC9060 Music/CC9068	034936
0-03-03-0024-0	Microphone	010258
1-09-01-0001-0	external loudspeaker	003067
0-07-16-0003-0	Przegub kulisty czteropunktowy	018416
0-24-00-0158-0	Display CC9060 Plus/CC9060Music/CC9068	054284
0-24-00-0192-0	Display CC9058	nicht angelegt
0-24-00-0138-0	Display CC 9056 Plus	nicht angelegt
0-07-16-0063-0	Przegub wieszaka CC9060	055928
0-12-07-0007-0	Carphone Private Handset	064896
0-VSM0518_LF	Micro female to lighting adapter	106772
0-07-0292-0_LF	Extension Cable with Mini-USB-Port	073201
0-07-0286-001_LF	Extension cord	075796